


↑  
↓



- 5) Using the locator pins to correctly locate, install steel support to post assembly with (2) #6 x 1-5/8" deck screws in bottom holes and (1) #10 x 1-1/2" pan head screw in top hole. Note: Ensure that the screws are tight before continuing assembly.
- 6) Place and locate the post crossarm over the steel support and to post assembly. Secure with (2) #6 x 1-5/8" deck screws.
- 7) Install the mounting plate to the post crossarm with (4) #10-24 x 1" hex head screws.

- 
- GIBRALTAR**  
INDUSTRIES  
TAYLORSVILLE, MS  
39168



**SOLAR GROUP**  
A GIBRALTAR COMPANY